

SPECORD[®] PC

200 / 205 / 210 / 250

UV VIS Spectrophotometer



Analytik Jena AG
Kundendienst
Konrad-Zuse-Str. 1
07745 Jena

Phone: Hotline: + 49 (0) 3641 77 74 07
Fax: + 49 (0) 3641 77 74 49
E-Mail: service@analytik-jena.de

General information about Analytik Jena AG
on the internet: <http://www.analytik-jena.de>

Copyrights and Trademarks

Microsoft, Windows XP, Windows NT, Windows 2000, MS Excel are registered trademarks of Microsoft Corp.

Publication No.: 221:416.23

Edition – April 2005
Technical documentation made by:
Analytik Jena AG

This documentation describes the state of this product at the time of publishing. It need not necessarily agree with future versions of the product.
Subject to change!

© Copyright 2005 Analytik Jena AG



Contents

1	Introduction	3
1.1	Intended use of the SPECORD.....	3
1.2	Notes on the User's Manual	4
2	Safety notes	5
2.1	Warning labels on SPECORD.....	5
2.2	General safety regulations	5
3	Technical data of the spectrophotometers	9
3.1	Optical data of SPECORD	9
3.2	General technical data of SPECORD	11
4	Device description and operating principle	13
4.1	Mechanical design of SPECORD	13
4.2	Design of subassemblies	14
4.2.1	Light sources	14
4.2.2	Spectrometer system and photometer section	16
4.2.3	Sample compartment	17
5	Installation and transport conditions	19
6	Installation and start-up.....	21
6.1	Connectors and display elements	21
6.2	Removing the transport lock	23
6.3	Connecting the SPECORD	24
6.4	Start-up.....	25
6.5	Switching the device off	26
6.5.1	Switching the deuterium lamp off	26
6.5.2	Switching the SPECORD off	26
7	Accessories	27
7.1	Standard cell holders	27
7.2	Receptacle for cells with turbid samples	28
7.3	Additional accessories	29
8	Care, maintenance, lamp change.....	31
8.1	Care and maintenance	31
8.2	Cleaning	31
8.3	Changing lamps	32
8.3.1	Note on the service life of lamps	32
8.3.2	Opening the flap of the lamp compartment	32
8.3.3	Changing the deuterium lamp	35
8.3.4	Changing the halogen lamp	37
8.4	Changing the desiccator	39
8.5	Changing fuses	39
9	Disposal	41
10	Index to Illustrations	43
11	Index to Overviews.....	43

1 Introduction

1.1 Intended use of the SPECORD

The SPECORD® is a powerful, computer-controlled double-beam spectrophotometer for the measurement of the transmission, absorbance, reflection as well as the energy of liquid and solid samples. It is designed for measurements in the spectral range 190 – 1100 nm.

The double-beam spectrophotometers of the SPECORD® family provide different spectral resolutions:

SPECORD® 200	1; 2 and 4 nm
SPECORD® 205	1.4 nm
SPECORD® 210	0.5, 1, 2 and 4 nm
SPECORD® 250	0.5; 1; 2 and 4 nm, with premonochromator

The optical system without electromechanical modulator ensures true real-time operation, so that even variations in the absorbance of references can be compensated during the measurement.

The internal wavelength calibration with a holmium oxide filter provides a high wavelength accuracy and reproducibility.

The SPECORD® complies with the regulations of the DAB (German Pharmacopoeia) and international regulations, such as PhEur., BP, USP or JPXIII.

In combination with the powerful WinASPECT® software, the SPECORD® is particularly suitable for the use in routine laboratories with a high sample throughput, but also provides solutions for special applications, if used in combination with the diverse accessories available.

1.2 Notes on the User's Manual

This manual contains the description of the following devices

- SPECORD® 200
- SPECORD® 205
- SPECORD® 210
- SPECORD® 250

If the descriptions equally refer to all three models, only the collective term SPECORD® will be used. If a property of an individual model shall be particularly stressed, the full name of the model will be mentioned.

In this manual, the following symbols are used to refer you to warnings and notes:



Warning!

Warning messages alert you to a specific procedure or practice which, if not followed correctly, could cause personal injury.



Caution!

Caution messages refer you to procedures which, if not observed, could result in damage to the equipment.



Dangerous electric voltage!



Emission of UV radiation!



Disconnect power cable!



Note

This note must be followed to obtain correct measurement results.

For easier navigation within the manual, the manual uses the following system:

- Chapters and illustrations are numbered consecutively.
- Every illustration has its own caption.
- Steps of operation are numbered.
- Cross-references are marked by an arrow (e.g. →Intended use of the SPECORD p.3)

2 Safety notes

2.1 Warning labels on SPECORD

Observe the warning labels on the SPECORD®!

The following warning labels have been affixed to the lamp housings of the SPECORD®:

**Danger! UV radiation!**

Do not look directly or indirectly via a mirror into the radiation emitted by the UV lamp. The lamp radiation may cause conjunctivitis!

**Danger! Hot surface!**

When lamps are switched on, their covers heat up strongly. If you intend to change the lamps or open the lamp covers, switch the lamps off and allow for a sufficient cool-down time.

2.2 General safety regulations

For your personal safety and for a trouble-free operation, carefully read this chapter before starting up the SPECORD®.

Observe all safety notes given in this manual and all messages and notes displayed by the control software on the screen.

In addition, observe the safety notes for system components of other manufacturers (e.g. PC, printer, autosampler) supplied together with the device.

In particular, you should also observe the safety notes given on the labels and the information on the use, storage and disposal of reagents, reaction cells and the notes on the package inserts of test kits.

**Intended use!**

The SPECORD®, including original accessories, may only be used for the applications described in this manual. The manufacturer cannot assume any liability for any other application, including that of individual modules or single parts. This also applies to all service or repair work that is not carried out by authorized service personnel. All warranty claims shall be forfeited.

**Local safety regulations!**

Observe the local safety regulations relevant to the operation of the device (e.g. labor-safety regulations, regulations for the prevention of and protection against accidents). References to possible risks given in this manual do not replace the relevant labor-safety regulations that are to be followed.

**Personnel!**

The SPECORD® may only be operated by appropriately qualified and trained personnel.

For that, the knowledge of the information provided by this manual is indispensable and taken for granted.



Emergency stop!

In the case of emergency, disconnect the SPECORD® and its components from line power by removing the power plug from the power outlet.



Electric shocks!

The SPECORD® is electrically powered. At several parts inside the system, **extremely hazardous electrical** voltages are accessible!

To ensure Protection Class I (protective earth connection) of the device, connect the power plug of the device only to a power outlet with protective earth conductor. The protective effect must not be undone by the use of an extension cable without protective earth conductor.

Before opening the device or removing any device covers, disconnect the power cable!

Before connecting the SPECORD® to the power outlet, make sure the line voltage supplied agrees with the operating voltage specified on the rating plate at the rear panel of the device. Operation of the device with any other operating voltage than that specified may result in the destruction of the device.

Only use fuses of the specified type.



Do not operate the device in explosion-risk rooms!



UV radiation!

Never look directly or indirectly, e.g. via a mirror, into the radiation emitted by the lamp to avoid the risk of getting conjunctivitis!

Therefore, switch off the lamp for lamp replacement!



Lamp damage!

Do not grasp functioning halogen and deuterium lamps on their glass bulbs.

Contamination on the bulb affects the radiation properties of the lamps.

Especially protect the beam-exit window of the deuterium lamp.

Make sure to remove the protective cap from the halogen bulb after having inserted it to avoid any risk of fire!

Non-observance will result in damage of the lamp.



Accumulation of heat

Heat accumulation might result in overheating and faults on the device.

Make sure not to cover the ventilation slots of the SPECORD®!

Before you switch on the SPECORD®, remove its dust cover!



Handling liquids

Take care to ensure that no liquids can enter the SPECORD® to avoid any damage to the device.



Risk of corrosion

Do not set up the device in the vicinity of aggressive vapors, e.g. strongly corrosive acid or caustic vapors! The vapors might corrode the connections, mechanical and optical components of the device.

Avoid exposing the sample compartment to strongly corrosive substances! For the analysis of such samples, use vapor-tight stoppered cells.

After the measurement, do not leave the samples unnecessarily long in the sample compartment of the device!

The SPECORD® was produced and tested in compliance with the following standards and regulations:

- DIN EN 61010-1 (IEC 1010-1)
- 73/23/EC
- 89/336/EC.

The SPECORD® meets the requirements as per Protection Type IP 20.

3 Technical data of the spectrophotometers

3.1 Optical data of SPECORD

Technical Data	SPECORD® 200 / 205 /210
Principle	Double-beam spectrophotometer with two large-area photodiodes
Optics	Monochromator with holographic concave grating Light split into two beams by a beam-splitting plate
Wavelength range	190-1100nm
Photometric display range	-8A ... 8A
Photometric measuring range	-3A ... 3A
Wavelength accuracy (with holmium oxide filter)*	$\leq \pm 0.5\text{nm}$
Wavelength reproducibility (with holmium oxide filter)*	$\leq \pm 0.05\text{nm}$
Photometric accuracy VIS at 546nm with Hellma F4 neutral-density filter	$\leq \pm 0.005$
Photometric accuracy UV with potassium dichromate as per Ph.Eur.	$\leq \pm 0.01$
Stray light at 200nm (KCl Merck 1.08164.0001)	$\leq 0.5\%T$
Stray light at 220nm (NaI)	$\leq 0.05\%T$
Stray light at 240nm (NaI)	$\leq 0.05\%$
Stray light at 340nm (NaNO ₂)	$\leq 0.05\%T$
Baseline noise at 500nm	≤ 0.00015 (RMS)
Long-term stability at 500nm	$\leq \pm 0.001$
Scanning speed	up to 6000nm/min

* allowing for tolerances of used standard

Technical Data	SPECORD® 250
Optical principle	Double-beam spectrophotometer with two large-area photodiodes
Optics	Premonochromator and monochromator with holographic concave grating Light split into two beams by a beam-splitting plate
Wavelength range	190-1100nm
Photometric display range	-8A ... 8A
Photometric measuring range	-4A ... 4A
Wavelength accuracy (with holmium oxide filter)*	$\leq \pm 0.5\text{nm}$
Wavelength reproducibility (with holmium oxide filter)*	$\leq \pm 0.05\text{nm}$
Photometric accuracy VIS at 546nm with Hellma F4 neutral-density filter	$\leq \pm 0.005$
Photometric accuracy UV with potassium dichromate as per Ph.Eur.	$\leq \pm 0.01$
Stray light at 200nm (KCl Merck 1.08164.0001)	$\leq 0.2\%T$
Stray light at 220nm (NaI)	$\leq 0.008\%T$
Stray light at 240nm (NaI)	$\leq 0.008\%$
Stray light at 340nm (NaNO ₂)	$\leq 0.008\%T$
Baseline noise at 500nm	≤ 0.00015 (RMS)
Long-term stability at 500nm	$\leq \pm 0.001$
Scanning speed	up to 6000nm/min

* allowing for tolerances of used standards

	SPECORD® 200	SPECORD® 205	SPECORD® 210	SPECORD® 250
Spectral bandwidth	1; 2; 4 nm variable	1.4 nm	0.5; 1; 2; 4 nm	0.5; 1; 2; 4 nm
Toluene / hexane resolution	> 2.1	> 1.7	> 2.1	> 2.1

Overview 3-1 Technical data of SPECORD® 200


3.2 General technical data of SPECORD

Weight	23.5 kg
Footprint (W x D)	ca. 1200 x 750 mm ² mit PC
Dimensions (W x H x D)	680 x 240 x 620 mm ³
Line voltage	230 VAC ± 10 % or 115 VAC ± 10 % (switchable by service)
Line frequency	47 ... 63 Hz
Power consumption	200 VA
Fuses: Line fuses	230 V~: T 3,15 AH/250V, Type 19181 (Wickmann) 115 V~: T 3,15 AH/250V, Type 19181 (Wickmann)
Radio noise suppression	as per EN 55011 Class A
Noise immunity	as per DIN EN 50082-1
Protection Type	IP 20
Data interfaces	2 x RS-232 for accessories 1 x USB port for the connection of an external PC 1 x RS-232 for the connection of an external PC
PC requirements for software: WinASPECT	Pentium processor 133 MHz, 16 MB RAM, Windows 2000 or higher

Overview 3-2 General technical data of SPECORD®

4 Device description and operating principle

4.1 Mechanical design of SPECORD



- 1 Premonochromator on SPECORD® 250 or toric illuminating mirror on SPECORD® 200/205/210
- 2 Light sources
- 3 Cover of spectrometer system and photometer section
- 4 Device control
- 5 Power supply module
- 6 Detector board
- 7 Holder for turbid samples
- 8 Mount for standard cell holder
- 9 Sample compartment

Fig. 4-1 Mechanical design of SPECORD®

The major subassemblies of the SPECORD® are:

Light sources	Halogen lamp and deuterium lamp generate the light that is monochromatized in the spectrometer system. Then, it passes through the sample.
Premonochromator (only on SPECORD® 250)	The premonochromator is a holographic grating that rotates synchronously with the monochromator grating. The thus obtained predisposition of light reduces stray light.
Spectrometer system	The spectrometer system is protected against extraneous light and dust by cover. The desiccator regulates the humidity inside the system.

Photometer section	This subassembly serves to split the light exiting the monochromator into sample and reference beam. The optical system shapes the beam cross-section in the sample compartment. The photometer section, too, is protected by cover .
Sample compartment	The sample compartment contains two pairs of carrier rods for the accommodation of various accessory units. To the support plate, two holders for the accommodation of cells (9) and the detector board are mounted.
Detector board	Two photodiodes are used as radiation detectors, which are Peltier temperature-controlled on SPECORD® 200/210/250.
Power supply module	The power supply modules supply the electrical voltage to the electronic system and the fans for the thermoelectric temperature control of the detectors on SPECORD® 200/210.
Device control computer	The device control computer coordinates the interaction of the subassemblies involved in the measurement processes.

4.2 Design of subassemblies

4.2.1 Light sources

SPECORD® 200 / 205 / 210




Fig. 4-2 Lamp compartment of SPECORD® 200/205/210

SPECORD® 250




Fig. 4-3 Lamp compartment of SPECORD® 250

The light sources used are a deuterium lamp (Fig. 4-2, 2) for the UV region and a halogen lamp (Fig. 4-2, 1) for the VIS region of the spectrum.

Depending on the position of reflecting mirror (Fig. 4-2, 3), which is mounted onto a moving magnet, the radiation of either deuterium or halogen lamp is sent onto the entrance slit of the monochromator. You can choose the wavelength at which the lamp is changed over a wide range using the WinASPECT® control and analysis software.

On the SPECORD® 200/205/210, the toric mirror (Fig. 4-2, 4) serves for imaging the light sources onto the entrance slit of the monochromator. To obtain the maximum possible energy of the deuterium lamp for the measurement, you can sensitively adjust the setscrew for mirror adjustment (Fig. 4-2, 5).

On the SPECORD® 250, the holographic grating of the premonochromator takes the place of the toric illuminating mirror (Fig. 4-4, 4).

4.2.2 Spectrometer system and photometer section




Fig. 4-4 Optical diagram of SPECORD®

The spectrometer system with the optical elements illustrated above – filter wheel, concave grating and slit assembly – works as monochromator.

The filter wheel contains the following filters:

4 color glass filters	Used to suppress unwanted radiation in the monochromator.
Holmium filter	Standard for the automatic recalibration of wavelengths.
2 blank positions	For the passage of non-dispersed light.
Block position	Needed for the generation of measured data.

The entrance and exit slits of the spectrometer system are mounted to the slit carrier. Depending on the device model, the slits allow the following spectral slit widths:

SPECORD® 200	1, 2, 4 nm
SPECORD® 205	1.4 nm
SPECORD® 210 / 250	0.5, 1, 2, 4 nm.

The imaging grating disperses the incident light and spreads it out into a spectrum.

Computer-controlled stepper motors drive the filter wheel, the slit carrier and the linear actuator for moving the grating. Because of the little number of moving parts used in the spectrometer system, the SPECORD® ensures a high reliability of its optical parameters.

In the photometer section, the mirror system divides the beam coming from the monochromator into sample and reference beam. The imaging mirrors shape the beam to the cross-sections needed in the sample compartment.

Spectrometer system and photometer section are protected against dust and reagents by a cover. However, corrosive reagents or strongly evaporating liquids should be inserted in the sample compartment only in stoppered cells.

4.2.3 Sample compartment




Fig. 4-5 Sample compartment

Sample (1) and reference beam (2) enter the sample compartment through the left-hand wall.

The mounts for the cell holders (8), (10) are arranged in front of the exit windows in the right-hand sample compartment wall.

The two pairs of carrier rods serve to accommodate the universal holder and other accessories, which easily clamp to the rods.

The receptacles for the cells (7), (9) with turbid samples are located directly in front of the detector at the right-hand sample-compartment wall.

Two 9-pin connectors (3), (4) allow the connection of electrically driven accessories, such as the cell changer or the sipper system.

The optical fibers of the measuring probe or the cables of the Peltier temperature-controlled cell holder or the cell changer are threaded through the recess in the rear wall of the sample compartment (5).

The three conduits (6,11) in the right-hand sample compartment wall are used for threading through the sample drain hose and two coolant hoses for the thermostat.

Two openings in the front of the device cover (12) are provided for the aspiration tubes of the super sipper system.

The illustration below shows the geometrical dimensions of the sample compartment.




Fig. 4-6 Dimensions of sample compartment

5 Installation and transport conditions

Installation conditions

Considering the dimensions of the SPECORD® and a clearance of approximately 100 mm to the sides and the front, the device needs a bench space of at least 860 x 720 mm.




Fig. 5-1 Dimensions of SPECORD®



Caution!

Do not cover the ventilation slots of the device!

Do not place any objects on the device!

Do not operate the device in explosion-risk rooms!

Keep aggressive vapors, e.g. strongly corrosive acid or caustic vapors away from the vicinity of the device.

The installation site of the SPECORD® must meet the following requirements:

- The place should be free of draft, dust, corrosive vapors as well as vibrations.
- Do not set up the SPECORD® near electromagnetic fields (e.g. of motors).
- Avoid dripping or splashing water near the instrument.
- Do not expose the device to direct sunlight or the radiation of heaters.
- Temperature range: + 15 ... + 35 °C
- Humidity: up to 90 % (at + 30 °C)

Conditions for storage and transport

For transport and storage, the following ambient conditions must be complied with:

- Temperature range in transport: -40...+70 °C
- Relative humidity in transport: up to 95 %

6 Installation and start-up

6.1 Connectors and display elements

The connectors and display elements of the SPECORD® are arranged easily accessible on front panel and side panels of the device.




Fig. 6-1 SPECORD® overall view

The LEDs indicating Power ON and lamp standby are located on the left side of the front panel of the SPECORD®. The LEDs light when the SPECORD® has been switched on and the lamps are on.




Fig. 6-2 Display elements on front panel

The line power input connector with fuse holder and the power switch are located on the left-hand side panel of the device.




Fig. 6-3 Connectors on left-hand side panel

On the right-hand side panel of the device, the following connectors are located: RS 232 and USB ports for the connection of a PC and the connectors for the xyz autosampler and the control of the Peltier temperature-controlled cell holder.





Fig. 6-4 Connectors on right-hand side panel

The transport locking screw is located at the rear side of the device. This screw must be removed when installing the SPECORD®. The optical fibers of fiber probes and the cables for the control of the Peltier temperature-controlled cell holders can be threaded through the opening in the lid. In normal operation, this opening should be closed with the black cover provided to prevent the entry of extraneous light, which would distort the analysis results.



- 1 Transport locking screw
- 2 Opening in lid for threading through cables of accessories

Fig. 6-5 Rear view of device

6.2 Removing the transport lock

The SPECORD® is equipped with a transport lock to prevent damage to the device and its optical system during transportation. The lock screw is located at the rear right on the bottom part of the device.




Fig. 6-6 Transport lock on SPECORD®



Note

The transport lock screw is not removed from the device, but is left in its holder in the SPECORD®.

If the device must be transported again or returned for repair to Analytik Jena AG, lock the transport lock again.

Releasing the transport lock

Using a screwdriver turn the transport lock screw (1) anti-clockwise as far as it will go.

Locking the transport lock

1. First, initialize the device to bring the monochromator into its starting position.
2. Switch the device off.

3. Using a screwdriver, turn the transport lock screw (1) clockwise as far as it will go.

6.3 Connecting the SPECORD



Observe correct position of device!

Move the SPECORD® only in upright position (observe label on transport case).
Do not turn the device upside down.

Release transport lock!

Loosen the transport lock screw located on the rear left of the SPECORD®.



Electric shock

Before connecting the SPECORD® and the PC to line power, make sure the available line voltage agrees with the operating voltage specified on the type labels. Operation of the devices on line voltages other than the specified operating voltage may result in their destruction.

Standard equipment

The standard equipment of the SPECORD® includes the following items:

- 2 cell holders
- Installation CD-ROM of WinASPECT® basic module
- Spare halogen lamp
- Deuterium lamp
- Power cable
- PC – SPECORD® connecting cable
- Spare fuses 5 x 20 T 3.15 A L
- User's Manuals for the SPECORD®, the accessories and the WinASPECT® control and analysis software.

Connecting SPECORD® and PC

1. Remove the device from its transport packaging and remove the plastic cover. Wait until the device has adjusted to the ambient temperature.
2. Remove the foamed plastic packaging from the SPECORD® sample compartment. The packaging contains the items included in the standard equipment (see above) and the installation disks for the WinASPECT® optional module you ordered.
3. Install the software on the PC (→ Refer to WinASPECT® User's Manual).
4. Insert the deuterium lamp following the instructions given in Section 8.3 Changing lamps p. 32.
5. Connect the SPECORD® (→ see 6.1 Connectors and display elements p. 21) to the PC (free COM port) using the supplied connecting cable.
6. Connect one power cable each to the SPECORD® and the PC. Connect the power cables of the SPECORD® and the PC to power outlets that are connected to the same phase of the line power supply (multiple socket outlet, if possible).

**Note**

When required, align the lamps following the instructions given in Section 8.3 Changing lamps, p. 32 after start-up.

6.4 Start-up

**Do not cover ventilation slots of the device!**

Take care to ensure that the ventilation slots on the top and on the right and left bottom of the SPECORD® are not covered. Do not place any objects in front of the openings. The suction intakes for the two fans on the bottom of the device must be kept free.

1. Start WinASPECT® software by a click on the program icon on the Windows desktop or by clicking the Start button on the taskbar:
Start / Programs / WinASPECT / WinASPECT.



Fig. 6-7 Program symbol of WinASPECT®

2. Using the power switch on the left panel of the device, switch the SPECORD® on (→ Refer to Fig. 6-3 Connectors on left-hand side panel, p. 22).
3. The green Power ON LED on the front panel of the device lights. (→ Refer to Fig. 6-2 Display elements on front panel, p. 21).
4. In WinASPECT® software, select the COM port for the SPECORD® – PC connection:
 - Activate the menu command **Measurement / Set Parameters** to open the window of the device driver **SPECORD xxx**




Fig. 6-8 Dialog box of SPECORD® 250 device driver

- Click on the **Device** tab.

- From the **COM Port** list box, select the COM port of your PC, to which the SPECORD® is connected.
- Click on **[OK]** to close the device driver window.

**Note**

The selected COM port will be saved and remain set until you change the COM port setting. Thus, you need not select it after every restart of the device.

-
5. Initialize the device:
Establish communication between SPECORD® and PC using the menu command **Measurement / Initialize Device**.

The SPECORD® is now ready for taking measurements.

**Note**

Please note that the SPECORD® reaches thermal stability only after a warm-up time of one hour. Therefore, you should not start precision measurements unless the device has warmed up.

6.5 Switching the device off

6.5.1 Switching the deuterium lamp off

If you have worked with the deuterium lamp and you are sure that you do not need it any longer this day, you can switch it off by software control following this procedure:

1. In WinASPECT®, activate the device driver with menu command **Measurement / Set Parameters**.
2. Activate the **Device** tab.
3. In the **Lamp change** at field, deactivate the **D2E automatically** function.
4. Close the device driver window by a click on **[OK]**.
5. Reinitialize the device using the following menu command: **Measurement / Initialize Device**.
6. A query appears on the screen asking you if you want to switch on the UV lamp. Click the **[No]** button.

The UV lamp goes out.

6.5.2 Switching the SPECORD off

We recommend that the SPECORD® be powered down by software control after you have finished taking measurements:

1. Exit WinASPECT® using menu command **File / Exit**.
2. Then, shut down the computer.
3. Finally, switch the SPECORD® off with the power switch.

**Note**

If you have finished the measurements on the SPECORD® but want to analyze the obtained results on the PC, you can also switch off the SPECORD® without shutting down the computer before.

7 Accessories

7.1 Standard cell holders

The standard equipment of the SPECORD® includes two cell holders for cells of up to 50 mm pathlength.

The mount for the cell holder is located on the right-hand sample compartment wall in front of the beam-exit window (→ Fig. 4-5 Sample compartment, p. 17). The cell holder is designed for cells having a pathlength of up to 50 mm and a width of 12.5 mm.




Fig. 7-1 Standard cell holder

Push the cell holder with its guide (2) from top onto the cell-holder mount.

The beam transmits the cells at a height of approximately 5 to 15 mm above the support of the cell holder.

Inserting the cell

1. Fill the sample into the cell up to a level of at least 20 mm.
2. Insert the cell so it rests against the right-hand support surface of the cell holder.




Fig. 7-2 Inserting the cell

**Note**

In absorbance measurements, the pathlength is one of the crucial factors. Therefore, it is important to insert all samples (samples and references) in the same location and position. In this way, you can avoid measurement errors caused by angular differences and parallel offset of the beam.

7.2 Receptacle for cells with turbid samples

In the measurement of strongly turbid samples, a considerable portion of the radiation does not exit the sample cell straightly, but is scattered within a solid angle. For photometrically accurate measurements it is necessary that the detector capture the total scattered radiation. For this purpose, the sample and the reference substance must be arranged as close to the detector as possible.

Therefore, the receptacles for the cells with scattering samples are located in the right-hand sample-compartment wall of the SPECORD® in front of the photodiode detectors (Fig. 4-5, 7 and 9 p.17). The receptacles can accommodate standard cells of 10 mm pathlength.

1. Remove the foamed-plastic caps covering the cell receptacles and insert the cells for the analysis.
2. After the measurement is finished, make sure to cover the cell receptacles again with the foamed-plastic caps. If you fail to do so, extraneous light might be incident on the detector and distort the results of the measurements.

7.3 Additional accessories

Optionally the following accessories are available for the **SPECORD**:

- Universal cell holder
- Thermostatted cell holder, water-cooled
- Thermostatted cell holder; Peltier-controlled
- Adjustable cell holder for micro, submicro or HPLC cells
- 6-cell changer, water-cooled
- 6-cell changer, Peltier-controlled
- Holder for cylindrical cells of up to 100 mm
- Holder for round cells
- Holder for solid samples
- 11° ... 60° variable Angle Reflectance Accessory
- Absolute Reflectance Accessory
- Universal sipper system with flow cell and peristaltic pump
- XYZ autosampler
- Fiber coupling with measuring probes
- 75-mm integrating sphere for transmission and diffuse reflectance
- PTC 100, Peltier temperature-controlled cell holder
- PTC 600, Peltier temperature-controlled 6-cell changer
- SMA fiber connector
- 8-cell changer (non-thermostatted, water-thermostatted or Peltier thermostatted)
- Combination of 2 x 8-cell changers

8 Care, maintenance, lamp change

8.1 Care and maintenance

The SPECORD® is largely free of maintenance.

To ensure your laboratory certification with device validation, Analytik Jena AG offers you a service/maintenance agreement.

User care and maintenance is limited to the following operations:

- Cleaning of sample compartment and device casing
- Lamp change
- Change of line fuses
- Change of desiccator

You should only use spares from Analytik Jena AG.

You can order consumables and wear parts by phone from our Service Department:

Hotline No.: + 49 3641-77-7407

In the case of malfunction of the device, please contact our Service Department. For the address, refer to the → inside cover page.

8.2 Cleaning

Avoid keeping filled cells unnecessarily long in the sample compartment to prevent the spectrometer from being affected by any solvent vapors.

Wipe off spilt samples in the sample compartment or on accessory units instantly with cleaning tissue.

Wipe off contamination on the instrument with a soft, clean cloth slightly moistened with a commercially available, neutral detergent.

8.3 Changing lamps

8.3.1 Note on the service life of lamps

The service life of lamps is:

- Halogen lamp: > 500 h (at 5.0 V operating voltage)
- Deuterium lamp: > 1000 h

The service life of the lamps is reduced, if the SPECORD® is frequently switched on and off. This particularly applies to the deuterium lamp, because of the relatively high ignition voltage required.

The following rule applies as criterion for the service life of the deuterium lamp: With one daily ON/OFF switching operation, its radiation intensity is allowed to decrease to 50% after 1000 hours.


The deuterium lamp must be changed, if its heating coil has burnt out, its energy is insufficient or the operating hours counter indicates 2000 h.

8.3.2 Opening the flap of the lamp compartment

The flap of the lamp compartment (front left corner of device cover) is to be opened to check the operating hours of the deuterium lamp, change the lamps or change the desiccator.

Opening the flap

1. Switch the SPECORD® off and allow the lamps to cool down for at least five minutes.
2. Release the lock (2) of the flap of the lamp compartment by folding the lock frontward so it sticks out from the SPECORD® approximately vertically.
3. Remove the flap of the lamp compartment by lifting it from below by 1 to 2 mm and then pulling it off to the left.



- 1 Flap of lamp compartment
- 2 Lock

Fig. 8-1 Opening the flap of the lamp compartment


In the open lamp compartment, you can see the deuterium lamp at the front left and the halogen lamp. Both lamps are enclosed by a protective cover.

SPECORD® 250

- 1 Protective cover of halogen lamp (two parts)
- 2 Knurled screw for protective cover of halogen lamp
- 3 Protective cover of deuterium lamp
- 4 Top part of protective cover of deuterium lamp
- 5 Desiccator

Fig. 8-2 Lamp compartment of SPECORD®, opened

SPECORD® 200 / 205 /210



- 1 Protective cover of halogen lamp (one part)
- 2 Knurled screw for protective cover of halogen lamp
- 3 Protective cover of deuterium lamp
- 4 Top part of protective cover of deuterium lamp
- 5 Desiccator
- 6 Illuminating mirror
- 7 Screw for adjusting the illuminating mirror

Fig. 8-3 Lamp compartment of SPECORD® 200 / 205 / 210, opened

Closing the flap of the lamp compartment

1. Put the flap of the lamp compartment from the left straight onto the bottom of the spectrometer.
2. Slide the flap to the right until the clips snap in.
3. Fasten the lock by folding it back to the flap.

8.3.3 Changing the deuterium lamp

**Risk of electric shock!**

Before changing the deuterium lamp, make sure to switch the device off with the power switch.

**Caution: Risk of burns!**

Allow the deuterium lamp to cool down to avoid the risk of burns!

**Emitted UV radiation!**


Never look directly or indirectly, e.g. via a mirror, into the radiation emitted by the lamp to avoid the risk of getting conjunctivitis!

**Dirt on beam exit window!**

Do not touch the glass bulb of the new deuterium lamp. Particularly avoid contamination on the quartz glass beam exit window! If you touched the glass bulb with your fingers, wipe the fingerprints off with a clean, lintfree cloth and pure alcohol. The performance of the lamp will deteriorate by contamination.

After you have removed the flap of the lamp compartment, the lamps are visible in their protective covers (Fig. 8-2 and Fig. 8-3).

1. Remove the top part of the protective cover of the deuterium lamp by pulling it upward.



- | | | | |
|---|----------------|---|----------------------------|
| 1 | Knurled screws | 3 | Operating hours meter |
| 2 | Guiding groove | 4 | Plug-and socket connection |

Fig. 8-4 Changing the deuterium lamp

2. Disconnect the three-pole plug-and-socket connection (4) by compressing the lateral straps and pulling the connection apart.
3. Loosen the knurled screws (1) and pull the deuterium lamp out of its holder.

4. Remove the new deuterium lamp from its packaging and insert it in the lamp holder taking care that the locating pin of the lamp holder fits into groove (2) of the lamp base.
5. Screw down the deuterium lamp by means of both knurled screws (1). Reconnect the lamp connector (4).
6. Finally, reattach the top part of the protective cover of the lamp acc. to Fig. 8-2 or Fig. 8-3.

Fine alignment of deuterium lamp of SPECORD® 200 / 205 / 210



Fine alignment on the SPECORD® 250 by the user is not planned!

On this device, the premonochromator is mounted in place of the toric illuminating mirror. The premonochromator operates synchronously with the main monochromator. Improper attempts of alignment may result in severe alignment faults!
If the energy of the deuterium lamp should be insufficient even after lamp replacement, contact our Technical Service!

Despite stringent manufacturing tolerances of the deuterium lamps, it may be necessary to realign the lamp after lamp change to ensure that maximum intensity of the lamp is incident on the entrance slit of the monochromator. For this purpose, you can slightly move the illuminating mirror by means of setscrew (Fig. 8-3, 7).



Caution!

Do not remove the protective cover of the halogen lamp during the alignment! The thus produced stray light will result in alignment errors!

1. Switch the SPECORD® on and initialize it. To this end, start WinASPECT® and activate the following menu command: **Measurement / Initialize Device**.
2. Set up a parameter record containing the following parameters:

Wavelength	230 nm
Integration time	0.5 s
Display	Energy
Cycle	Automatic, 200x
3. Start the measurement with the sample compartment kept closed. Keep the flap of the lamp compartment open.
4. Sensitively turn the setscrew (11) in both directions until the detected energy reaches its maximum.
5. This adjustment also influences the alignment of the deuterium lamp. However, the variation is comparatively small and normally negligible.
6. Finally, close the flap of the lamp compartment.



Note

Please note that the deuterium lamp needs a warm-up of one hour after ignition to reach full thermal stability.

8.3.4 Changing the halogen lamp

**Electric shock!**

Before changing the halogen lamp, make sure to switch the device off with the power switch.

**Caution: Risk of burns!**

Allow the halogen lamp to cool down to avoid the risk of burns!

**Emitted radiation!**

Never look into the lighting lamp as the radiation may cause eye injury!

**Caution!**


Do not touch the glass bulb of the lamp to avoid any contamination affecting its performance!

Open the lamp-compartment flap. The protective cover of the halogen lamp is visible.

1. Loosen the knurled screw of the protective cover of the halogen lamp (Fig. 8-2, 2) and remove the front part of the protective cover.

**Note**

The protective cover of the halogen lamp of the SPECORD® 200/205/210 was technically revised. On devices produced before, the protective cover consists only of a single part. In this case, remove the complete protective cover upward.



- 1 Rear part of protective cover of halogen lamp
- 2 Knurled screws
- 4 Holder of halogen lamp
- 3 Adjusting screws for halogen lamp holder
- 4 Halogen lamp

Fig. 8-1 Changing the halogen lamp

2. Loosen the two clamping screws (2).
3. Pull the defective halogen lamp (5) out of its holder (3).
4. Remove the new halogen lamp from its packaging, but keep the protective sheath attached.
5. Insert the new halogen lamp taking care to ensure that the notch at its base encloses the pin in the bottom part of the holder.
6. Reattach the protective cover of the halogen lamp and refasten it.

Fine alignment of halogen lamp

Check the alignment of the halogen lamp.

1. For this purpose, switch the SPECORD® on and initialize it. To this end, start WinASPECT® and activate the following menu command: **Measurement / Initialize Device**.
2. Exit WinASPECT® to run the Service Check routine and activate the Service Check routine as follows:
Click on the **[Start]** button of the Windows taskbar. In the Programs folder, click on the **WinASPECT** folder. There, click on the **Service xxx** command. This will bring up the **SPECORD xxx - Service Check** dialog box.
3. Click on the **[Zeroth Order]** button and choose the halogen lamp (**HL – Lamp**).
4. View the image of the sample beam in the sample compartment by holding a white sheet of paper in the plane where normally the cell is placed.
There, a 7 – 8 mm high and 1 – 2 mm wide light spot should be visible that is evenly illuminated from top to bottom.
5. If you find that the light spot on the sheet of paper is badly uneven, verify that the halogen lamp is correctly seated.
6. Perform wavelength correction and check the zeroth order and automatic adjustment of gain stages.
7. If you are not satisfied with the alignment of the halogen lamp, loosen the fastening screws (Fig. 8-1, 3) and move the lamp sensitively while running an energy measurement as described above for the fine alignment of the deuterium lamp on the SPECORD® 200/205/210. For that, the ideal wavelength is 500 nm.



Note

Please note that the halogen lamp needs a warm-up of about one hour after switch on to reach full thermal stability.

8.4 Changing the desiccator



Danger! Hot surface!

Before replacing the desiccator, switch off the SPECORD®. Allow for a sufficient cool-down time of the lamps. Touching the hot lamp surfaces housings may cause burns!

The desiccator protects the optical system of the SPECORD® against too high air humidity. The desiccator is accessible, when the lamp compartment has been opened (→ Refer to Fig. 8-2, 5, p.33)

Especially in tropical countries, the adsorption capacity of the desiccator should be checked regularly. The adsorption capacity of the desiccator is exhausted, if the color of the indicator paper in the inspection window has changed from blue to pink-yellow.

For changing the desiccator, follow this procedure:

1. Open the flap of the lamp compartment by folding the lock frontward so it sticks out vertically. Lift the flap from below by 1 to 2 mm and then pull it off to the left.
2. Using a flat tool, such as an appropriate coin, unscrew the desiccator from its holder.
3. Remove the new desiccator from the packaging and screw it into the holder.
4. Finally, close the flap of the lamp compartment.

Used up desiccators can be reused after heating them up for five hours in a drying oven. New desiccators are available from our Service Department (→ for the address, refer to the inside cover page).

8.5 Changing fuses

If the line fuses are defective, you can change them yourself.



Risk of electric shock!

Before changing the fuses, make sure to switch the SPECORD® off with the power switch and disconnect the power cable from the power input connector of the device.

1. Remove the power cable from the SPECORD®.
2. Open the fuse holder (→ Refer to Fig. 6-3, p. 22) by pulling on its lid.
3. Replace the defective line fuses.
Make sure to use only the following fuse types:
 - T 3.15 H/250 V, Type 19181 for line voltages of 150 VAC and 230 VAC.
4. Close the fuse holder again.
5. Reconnect the power cable to the power input connector of the SPECORD® and the power outlet.
6. Switch the SPECORD® on again.

9 Disposal

The owner/operator of the SPECORD® must ensure to dispose of the waste material (samples) cropping up in the analyses in accordance with the relevant legal and local regulations.

When the service life of the device is over, dispose of the device with its electronic components as electronic scrap observing the relevant regulations.

You can also return the SPECORD® to Analytik Jena AG for disposal. Please contact our Technical Service.

10 Index to Illustrations

Fig. 4-1	Mechanical design of SPECORD®	13
Fig. 4-2	Lamp compartment of SPECORD® 200/205/210	14
Fig. 4-3	Lamp compartment of SPECORD® 250	15
Fig. 4-4	Optical diagram of SPECORD®	16
Fig. 4-5	Sample compartment	17
Fig. 4-6	Dimensions of sample compartment	18
Fig. 5-1	Dimensions of SPECORD®	19
Fig. 6-1	SPECORD® overall view	21
Fig. 6-2	Display elements on front panel	21
Fig. 6-3	Connectors on left-hand side panel	22
Fig. 6-4	Connectors on right-hand side panel	22
Fig. 6-5	Rear view of device	23
Fig. 6-6	Transport lock on SPECORD®	23
Fig. 6-7	Program symbol of WinASPECT®	25
Fig. 6-8	Dialog box of SPECORD® 250 device driver	25
Fig. 7-1	Standard cell holder	27
Fig. 7-2	Inserting the cell	27
Fig. 8-1	Opening the flap of the lamp compartment	32
Fig. 8-2	Lamp compartment of SPECORD®, opened	33
Fig. 8-3	Lamp compartment of SPECORD® 200 / 205 / 210, opened	34
Fig. 8-4	Changing the deuterium lamp	35

11 Index to Overviews

Overview 3-1	Technical data of SPECORD® 200	10
Overview 3-2	General technical data of SPECORD®	11